

TABLET SAFETY INSTRUCTIONS

Document prepared in accordance with Regulation (EU) 2023/988 on general product safety (GPSR)

Purpose of the Document

The purpose of this document is to ensure the safe use of tablets by identifying potential hazards and presenting practical preventive measures, in line with the current legal requirements of the European Union regarding product safety.

1. General Hazards and Precautionary Measures

1.1 Risk of Electric Shock

- Use only certified chargers and cables provided by the seller.
- Do not charge the tablet using a damaged power cable.
- Avoid operating the device with wet hands or charging it in a humid environment (e.g., bathroom, kitchen).

1.2 Risk of Overheating

- Do not leave the tablet in places exposed to high temperatures, such as inside a car or under direct sunlight.
- Ensure proper ventilation — do not block cooling vents and avoid storing the device in closed, heated spaces.
- Do not puncture, crush, or heat the battery. Do not throw it into fire. A damaged battery may ignite or explode, posing a burn or fire hazard.

1.3 Mechanical Damage

- Protect the device from impacts and drops by using a dedicated protective case.
 - Do not store the tablet in a bag with sharp or hard objects to prevent screen cracks or scratches.
-

2. Usage-Related Hazards

2.1 During Initial Setup and Configuration

- Follow the manufacturer's instructions when powering on the device for the first time.
- Avoid connecting the tablet to damaged USB ports or faulty power supplies.

2.2 During Daily Use

- Do not use the tablet near liquids — spills may cause serious damage.
- Avoid strong vibrations and mechanical shocks, which may affect the device's performance.

2.3 In Challenging Environmental Conditions

- Do not use the tablet in environments with high humidity or heavy dust unless the device is specifically designed for such use.
 - If necessary, use protective cases that guard against water and dust.
-

3. Maintenance and Storage

3.1 Cleaning the Device

- Use a soft microfiber cloth slightly dampened with water to clean the screen and casing.

- Avoid using strong detergents or chemicals that could damage the surface of the device.

3.2 Technical Inspection

- Regularly check the condition of ports and cables — look for signs of wear, damage, or dirt.
- If any issues are detected, consult an authorized service center.

3.3 Storage Conditions

- Store the device in a dry, cool place, away from heat sources and moisture.
 - Avoid prolonged exposure to direct sunlight.
-

4. Additional Recommendations

4.1 Child Safety

- A tablet is not a toy — keep it out of reach of children to avoid the risk of damage or swallowing of small parts.

4.2 Modifications and Interventions

- Do not attempt to repair or modify internal components of the tablet yourself — this may compromise safety, affect device performance, and void the warranty.
 - In case of liquid damage, turn off the tablet immediately, and if possible, remove the battery. Dry the device and take it to a service center.
-

Summary

Following these instructions significantly reduces the risk of accidents, device damage, and health hazards. A tablet is a device that requires proper handling and use in accordance with its

intended purpose. Ensure your safety and that of your surroundings by adhering to the manufacturer's recommendations and the applicable EU legislation.